



www.anfieldsensors.com
Tel: (905) 303-8700
sales@anfieldsensors.com

**INSTALLATION INSTRUCTIONS
TEMPERATURE TRANSDUCERS
TTLM SERIES**

General Instructions:

Please check the model designation of the temperature transducer to ensure it is being used within its designed range prior to installation.

Electrical Installation:

Please check the wiring code for electrical installation process.

Mechanical Installation:

Install seals or apply thread sealants to the process connection as required. Install the unit using a 11/16" wrench and tighten 2-3 turns from finger tight.

For detailed information please consult ANSI B1.20.3 Dry Seal.

Table 1. Installation

Process Connection	Installation Turns	Notes
3/8"-18 PTF SAE External	2 - 3 T.F.F.T *	Sealant Not Required

*Note! * T.F.F.T Turns from finger tight.*

P109568 REV 0