

www.andieldsensors.com Tel: (905) 303-8700 sales@anfieldsensors.com

## INSTALLATION INSTRUCTIONS PRESSURE SWITCHES SPA / SPF SERIES

Please check the model designation of the pressure switch to ensure it is being used within its design range. The switch should be wired in accordance with the tables and schematic below. Follow all applicable electrical requirement per the local electrical authority in your area.

## Wire/Connector Termination

| Contact         | Spades<br>SP   | Flying Leads<br>FL | DIN<br>H, HR, HC, HCR, HN, HNR | Weather Pack<br>FLWF, FLWM |              |
|-----------------|----------------|--------------------|--------------------------------|----------------------------|--------------|
| Common          | C (see Fig 2)  | Black              | Pin 1                          | Α                          | Pin A/ Pin 1 |
| Normally Closed | NC (see Fig 2) | Blue               | Pin 2                          | С                          | Pin C/ Pin 2 |
| Normally Open   | NO (see Fig 2) | Red                | Pin 3                          | В                          | Pin B/ Pin 2 |

## Electrical Ratings (\*UL surrounding air temperature rating is 131'F)

| Model           | Standard Rating   | UL rating * |                        |
|-----------------|-------------------|-------------|------------------------|
| Standard 5 amp  | 12-24VDC: 5A (0)  | 125VAC: 5A  | 1                      |
| Micro switch    | 125VAC: 5A (0)    |             | Fig 1. Circuit Diagram |
|                 | 250VAC: 3A (0)    |             |                        |
| Optional 10 amp | 12-24VDC: 10A (2) | 125VAC: 10A | SPDT NC                |
| Micro switch    | 125VAC: 10A (2)   | 250VAC: 6A  | 2                      |
|                 | 250VAC: 6A (2)    |             | C 1                    |
| Optional Gold   | 12VDC: 20mA       | NA          | NO                     |
| Micro switch    |                   |             |                        |

## **OPERATING SPECIFICATIONS & CHARACTERISTICS**

| MODEL   | ADJUSTMENT<br>RANGE<br>(psi) | AVERAGE<br>DIFFERENTIAL | PROOF<br>PRESSURE<br>(psi) | ADJUSTMEN<br>(psi per turn |
|---------|------------------------------|-------------------------|----------------------------|----------------------------|
| SPA - 1 | 3 - 7                        | 6-20% of setting        | 350                        | 1                          |
| SPA - 2 | 5 - 30                       | 6-20% of setting        | 350                        | 3                          |
| SPA - 3 | 25 - 150                     | 6-20% of setting        | 350                        | 25                         |

Step 3: The adjustment screw may be potted with silicone to prevent moisture ingress through the adjustment screw.



Fig 3. Setting

ADJUSTING THE SET POINT: (Default setting is the lowest setting within range) Step 1: Insert a 5/64" or 2mm allen key into the adjustment screw opening. (Fig 3)
Step 2: Turn the screw clockwise to increase the set point or counter clockwise to decrease.

P108268 REV 0