

## Ordering Information

### Field Adjustable

1 2 3 4 5 (Optional)  
**SPVL** - **2** - **2M** - **A** - **SP** - **2**

### Factory Preset

1 2 3 4 5 (Optional)  
**SPVF** - **17F** - **2M** - **A** - **SP** - **2**

## 1 - Pressure Selection:

Field Adjustable - Select Model Code

Insert set point value XXX followed by: R, F, MR, or MF

Model	Adjustment Range	
	inHg	Millibar
<b>1</b>	1.1 - 3	37 - 101
<b>2</b>	4 - 8	135 - 270
<b>3</b>	9 - 17	305 - 575
<b>4</b>	18 - 22	610 - 745

OR

Set Point	Direction	Description
XXXX	<b>R</b>	inHg Rising Vacuum
	<b>F</b>	inHg Falling Vacuum
	<b>MR</b>	Millibar Rising Vacuum
	<b>MF</b>	Millibar Falling Vacuum

## 2 - Thread Options:

- 2M** - 1/8 NPT male
- 4M** - 1/4 NPT male
- 2G** - 1/8 BSPP male, G1/8
- 4G** - 1/4 BSPP male, G1/4

## 3 - Circuit:

- A** - SPST (Normally Open)
- B** - SPST (Normally Closed)

## 4 - Electrical Termination:

- FL** - Flying Lead 18" long, 18 AWG
- FLWF** - Flying Lead Weatherpack connector, female, Tower, 10" long leads
- FLWM** - Flying Lead Weatherpack connector, male, Shroud, 10" long leads
- FLDP** - Flying Lead Deutsch connector, plug, 10" long leads
- FLDR** - Flying Lead Deutsch connector, receptacle, 10" long leads
- FLCM** - Flying Lead Metripack, male, 150 series, 10" long leads
- FLCF** - Flying Lead Metripack, female, 150 series, 10" long leads
- FLPM** - Flying Lead Metripack, male, 280 series, 10" long leads
- FLPF** - Flying Lead Metripack, female, 280 series, 10" long leads
- SP** - 1/4" Spade
- TS** - Terminal Screws, #8-32

## 5 - Options (Omit if not required):

- 2** - EPDM Diaphragm
- 9** - 304 Stainless Steel Housing
- 20** - Seal adjustment Screw
- 30** - Rubber Boot - Removable



Note: Please see page 52 for other available options